



Installation

The Installation procedure below details the recommended installation steps for all Renaza mosaic wall tiles. Bella Lujo recommends that installations be undertaken by a qualified tradesperson (Tiler) or experienced home renovator.

Step 1: Renaza mosaic tiles must be installed onto a solid surface, for example – gyprock, fibrous cement sheeting, brick, render, etc.

All surfaces must be clean and free of dirt and oil.

Step 2: Set out – measure the area to confirm dimensions, determine if any Renaza Tiles will require cutting, etc.

Step 3: Apply Adhesive* evenly to the back of each Renaza mosaic wall tile ensuring inclusive of each individual mosaic timber piece. Place and press each tile onto the wall until the adhesive takes hold.

Cutting Renaza Mosaic Wall Tiles

It is recommended Renaza mosaic wall tiles are cut using a compound mitre saw with a timber cutting blade.

Your Safety is Paramount – please ensure ALL necessary safety equipment (eye protection, ear plugs, dusk mask, etc) is used.

Adhesive

Bella Lujo recommends a flexible construction adhesive is used on Renaza mosaic wall tiles. Bostik Ultraset SF (Solvent Free) is the recommended brand of construction adhesive suitable for installation of Renaza feature tiles. Follow the application instructions of any adhesive used, as a guide, allow an application rate of approximately one litre of flexible construction adhesive per one square metre of Renaza mosaic wall tiles.



Bostik Ultraset SF 'Brown'
(Solvent Free)
> [view product spec sheet](#)

